

#### 4.Temperature detector

##### 1. Learning goals

In this lesson, we will learn to use micro:bit and Wrist:bit make temperature detector.

##### 2.Code and analysis

```

1  from microbit import *
2  import microbit
3  import music
4
5
6  while True:
7      value = temperature()
8      microbit.sleep(500)
9      if value > 10 and value < 30:
10         pin2.write_analog(0)
11         display.scroll(str(value))
12     elif value >= 30 or value <= 10:
13         pin2.write_analog(1023)
14         music.play(music.ENTERTAINER)
15         display.scroll(str(value))
16
17
18

```

##### **from microbit import \***

This code is to import everything from the microbit library, and any program need to uses import this library.

**import music:** Import music library.

**temperature():** Return the temperature of the current micro:bit detection,unit is °C.

**write\_analog(value):** Outputs a PWM signal on the pin, whose duty cycle is proportional to the value provided.

**Tips:** The value can be an integer or a floating point number between 0 (0% duty cycle) and 1023 (100% duty cycle).

Because the vibration motor on the hardware circuit is connected to the P2 pin of the micro:bit board, we need to set P2 pin in program.

display.scroll() scrolls horizontally on the display. If the value is an integer or a floating-point number, the integer is first converted to a string.

##### **Note:**


1 - The capital letter/lowercase letters must be distinguished !

- 2 - Correct spelling!
- 3 - Keywords such as # need a space between the content.
- 4 - You can only use the Tab key (tabulation key) for indentation.


### 3. Programming and downloading

3.1 You should open the Mu software, and enter the code in the edit window, , as shown in figure .


**Note! All English and symbols should be entered in English, and the last line must be a space.**



3.2 As shown in Figure, you need to click the Check button to check if our code has an error. If a line appears with a cursor or an underscore, the program indicating this line is wrong.



3.3 You need to connect the micro data cable to micro:bit and the computer, then click the Flash button to download the program to micro:bit.



#### 4. Experimental phenomena

After the program is successfully downloaded. Micro:bit dot matrix will scroll display temperature data.

When the ambient temperature is higher than 30°C or lower than 10°C, buzzer will play music and the vibration motor will rotate.

When the ambient temperature is between 10°C and 30°C, music and vibration motors will stop.