

## 2.RGB light change color

### 1. Learning goals

In this lesson, we will learn to how to control RGB light on wrist:bit change different color.


### 2. Programming method

**Mode 1 online programming:** First, we need to connect the micro:bit to the computer by USB cable. The computer will pop up a USB flash drive and click on the URL in the USB flash drive: <http://microbit.org/> to enter the programming interface to program.

**Mode 2 offline programming:** We need to open the offline programming software. After the installation is complete, enter the programming interface, click 【New Project】 , you can program.


### 3. Looking for blocks

The following is the location of the building blocks required for this programming. Before programming, we need to add Neopixel extension pack.




Extensions


Search or enter project URL...




**devices**  
BETA - Camera, remote control and other Bluetooth services. App



**radio-broadcast**  
Adds new blocks for message communication in the radio



**servo**  
A micro-servo library



**neopixel**  
AdaFruit NeoPixel driver  
[Learn more](#)

Search...

- Basic**
- Input
- Music
- Led
- Radio
- Loops
- Logic
- Variables
- Math
- Neopixel
- Advanced
- Functions
- Arrays
- Text
- Game

**show icon**


**show string** "Hello!"

**clear screen**

**forever**


**on start**

**pause (ms)** 100



#### 4. Combine block

The summary program is shown below.



Due to RGB is connected to the P1 pin of the micro:bit on the hardware circuit, and there is one RGB light on the bitmotion:kit expansion board, the RGB light pin needs to be set to P1, and the number of LEDs is also set to 1.

### **5. Experimental phenomena**

After the program is successfully downloaded, the micro: bit dot matrix will display butterfly pattern. RGB lights will become red-> green->blue->white, the time interval is 1s.